

Installation pour #008-19301: Pour les lisses Everlaster carbide blade-z modèle UNIVERSELS #008-19301, il se peut que vous soyez obligé de percer vos propres trous selon vos skis. Les lisses universelles n'ont pas de papier d'installation. Vous devez adapter vous-même les lisses à vos skis. Prenez le temps de bien mesurer avant de percer vos trous. Le 6 pouces de carbure doit être le plus possible centralisés avec le centre de votre pivot de ski.

Installation for #008-19301: Concerning the UNIVERSAL Everlaster carbide blade-z model # 008-19301, it may be that you need to drill and find the position of bolts to do the installation for this kind of carbides. Our UNIVERSAL carbides don't have instruction sheet to help you to do this installation. You need to adapt these carbides to your skis yourself. Take your time when you measure before to drill in your skis. Maybe that our bolts can fit directly in your original holes ski's, but maybe not. The 6 inches of carbide need to be centralized, the most possible, with your middle of ski (swivel).

